



**Pro Pad Inc.**  
*Premium Motorcycle Products*

# Installation Instructions for #FB-EXT



## **Kit Includes:**

- (3) Large Bolts
- (3) Large Spacers
- (2) Small Bolts
- (1) Long Spacer with Holes

## **FOR THE RIGHT SIDE:**

- From the kit use -
- (2) Round Spacers
  - (2) Large Bolts

Take off the floorboard at the frame. Using the large bolts, attach the floorboard back to the frame with the round spacers in between the frame and the floorboard arms. Tighten all bolts.

## **FOR THE LEFT SIDE:**

**NOTE: Have someone hold the bike or put it on a stand as the kickstand will be loose during the install of the left side.**

- From the kit use -
- (1) Large Bolt
  - (1) Round Spacer
  - (2) Small Bolts
  - (1) Long Spacer with Holes

Remove the left floorboard from the frame. Reattach the front arm using the large bolt and round spacer. Loosely tighten. Attach the rear arm using the long spacer and 2 small bolts. Tighten up all the bolts.