

## Installation instructions for IMPAXX Tour Pack- Slim Line & Ultra Slim

Components included:

Top (with rubber gasket) and bottom shell

Latch (with lock and keys), 2 hinges and stainless hardware (24 button heads with washers).

Back rest pad with mounting nuts

Diamond quilted PPI bottom liner

Tether with mounting bolts & Top magnet & LED light

Missing something? Please call 704 660 1084 and we'll get it right out.

### ***-Tools you'll need to make this assembly easy-***

***2.5mm hex wrenches, 10mm socket, phillips head screwdriver, 5/16" drill, glue***

1. Drill the backrest pad holes for the top portion of the tour pack.
  - a. Using the template, center the middle hole and mark the holes for drilling
  - b. Use a 5/16" drill to drill the holes
  - c. Check the fit by attaching the backrest pad without securing the 10mm nuts.
  - d. Remove backrest pad

Before attaching back rest pad, bolt in the large portion of the tether (see #5).

- e. Remove the nuts and push the 3 backrest bolts through the drilled holes.
  - f. Secure backrest by reattaching 10mm nuts on to bolts. Blue Loctite is recommended.
2. Remove and inspect latch/hinges
  - a. Bolt on main latch to bottom shell using the longer button head bolts with washers.
    - i. Turn in each bolt just 2 turns until all 4 bolts are started.
    - ii. Now with all 4 bolts started, tighten all of bolts but not overtighten, bolt head may strip.
      1. Using 2 button heads attach the lock to the latch.
  - b. Locate the catch (thin metal part) and hinges- flip top shell upside down.
    - i. Attach catch using button head bolts with washers.
    - ii. Attach the 2 hinges using 8 button head bolts.
      1. Hinges are not the same, one is the for the front and one of the back. Hinges follow the contour of the lid of the shell.

2. Screws go into the recessed area of the top of the shell and screw into the top of the hinge. However, button can be used as well if you run into issues. Thread screws in but do not tighten
3. Thread button head bolts into lower holes of hinges.
4. Once all bolts are started, tighten all bolts, repeat for each hinge.
3. With top of the shell upside down- glue in the rubber seal into the channel of lid.
  - a. Lay a bead of glue (super glue, weather trim glue or gorilla glue work well).
  - b. Lay the rubber seal on to the bead starting with the middle (should you find the rubber a bit short, it's ok to put in a connecting piece with the additional material).
4. Now let's put the whole thing together. (You'll need another set of hands for attaching the top lid to the bottom portion).
  - a. Attach the bottom portion of the hinges to the bottom of the tour paxx using the longer button head screws with washers.
  - b. Start all four screws in each of the 2 hinges before tightening them. This will help align the top of the tour pack to the bottom portion.
  - c. Locate the remaining 2 black screws and attach the tether to the bottom portion of the tour pack in the 2 pre-drilled holes. Cloth tether should freely release and retract when opening and closing tour pack.
5. For mounting the tour pack to your 2014+ style Raxx brand quick detach tour pack rack or other makes. There are 4 recessed holes in the bottom portion of the tour pack. Use a 5/16" or 3/8" drill to drill out the holes. Your Paxx will work with other non 2014 style tour pack racks, we just don't mark the holes for them.
6. Now that your Paxx is attached to your Raxx, lay the liner in to the bottom portion of the IMPAXX tour pack. Once properly positioned begin to remove the adhesive backing and push onto tour pack wall. The embroidered Tourpaxx.com should be parallel and readable with the latch.

**Congratulations! You're all done!**

Video assembly instructions can be found online at [tourpaxx.com](http://tourpaxx.com)

Be sure to mail in your warranty card or register your Paxx at [thepropad.com](http://thepropad.com) (under the *contact us* section)

Thank you for your business!

Questions or Comments? Call 704 660 1084 or email [info@thepropad.com](mailto:info@thepropad.com)